



Humidi Mist

Trouble Shooting

HUMIDI MIST DOESN'T SEEM TO BE WORKING

1. Check if the power cable is plugged correctly into the body of the unit and wall socket and that power is available.
2. Check that you have turned the adjustment dial to an on position (you would hear a click sound).
3. Check if the water reservoir is full of water.
4. Check that the no spill valve is not clogged.
5. Check that the hose is not kinked and not damaged or blocked with water. Drain any excess water out and reassemble.
6. Check the spray bar and elbow joints are free from debris/water and is not damaged. Drain any excess water out and reassemble.

IF ALL ATTEMPTS FAIL, PLEASE GET IN TOUCH WITH YOUR LOCAL REPTILE ONE RETAILER