



Fan Heater Light

Hints & Tips for Best Results

Lighting:

Duplicate normal photo time of twelve hours of light and twelve hours of nocturnal lighting if required. For best UV results, ensure animal has a basking site minimum 300mm from light tube.

Trouble Shooting

LIGHT DOES NOT WORK

1. Ensure the plug is inserted correctly and the switch is in the on position.
2. The lamp may require replacing.

Changing the Lamp

Refer over leaflet for parts identification.

1. Ensure your hands are dry turn off and remove the plug from the receptacle.
2. Remove the light from the reptile enclosure.
3. Remove the lamp cover.
4. Pull the lamp from the light unit, do not twist the lamp.
5. Align the pins on the new lamp with the two holes in the light unit and push the lamp into place.
6. Replace the lamp cover and fix the light unit back into position above the reptile enclosure.
7. Plug the light back into the power receptacle and turn it on.